





















































Universal Standard ATF Adapter Hose Chart

Part #	Hose #	Photo	M/F	Vehicle Description
941802	# 52		M	Chrysler with 5/8" Diameter Lines Dodge 1500 Series Truck (5.9L) <i>[5/8-18 Thread]</i>
941801	# 51		F	
941817	# 67		M	Chrysler, Ford Aerostar, Jaguar, Mercedes, & Cadillac <i>[1/2-20 Thread]</i>
941816	# 66		F	
941815	# 65		M	Jeep Cherokee, Ford Escort <i>[14-18 NPT]</i>
941825	# 75		F	
941835	# 87		M	Dodge Durango/Dakota <i>[9/16-18 Thread]</i>
941836	# 88		F	
941803	# 53		M	General Motors with 3/8" Tube Diameter Lines Ford F-150 (5.4L), Fusion, Contour <i>[5/8-18 Thread]</i>
941807	# 57		F	
941820	# 70		M	General Motors with 5/16" Tube Diameter Lines Ford Expedition <i>[1/2-20 Thread]</i>
941821	# 71		F	
942163S	GM Adapter		M	GM w/ Quick Disconnect (942162 - Blue Quick Disconnect Tool) Dodge Charger [Adapter mates with Hose #66] <i>[3/8" Diameter]</i>
941805	# 55		F	
940329	3/8" Adapter		M	Ford Windstar, Freestar, Focus, F-150 Ford Transit Van (2009+) [Adapter mates with Hose #66]
941805	# 55		F	
940334	5/16" Adapter		M	Lincoln Continental, Ford Taurus [Adapter mates with Hose #66]
941813	# 63		F	
941818	# 68		M	Ford with Large Nut Adapter <i>[5/8-18 Thread]</i>
941819	# 69		F	
941823	# 73		M	Ford with 5/16" Small/Long Nut Adapter <i>[1/2-20]</i>
941822	# 72		F	
940875	# 79		M	Ford Escort <i>[Banjo Fitting M14x1.5 Thread]</i>
940874	# 78		F	
941923	1/2" Adapter		M	Ford F-150 (2009); Ford Escape (2001-2009) [Adapter mates with Hose #66]
941809	#59		F	
941925	3/8" Adapter		M	Ford Focus (2006+) [Adapter mates with Hose #66]
941805	#55		F	

Universal Standard ATF Adapter Hose Chart

Part #	Hose #	Photo	M/F	Vehicle Description
941828	# 80		M	Import <i>[1/4" Diameter]</i>
941829	# 81		F	
941830	# 82		M	Infiniti, Lexus, and BMW <i>[9/32" Diameter]</i>
941813	# 63		F	
941831	# 83		M	Toyota, Nissan, Honda, Ford and Chrysler <i>[3/8" Diameter]</i>
941805	# 55		F	
941832	# 84		M	Toyota, Nissan & Honda <i>[1/2" Diameter]</i>
941809	# 59		F	
941841	# 89		M	Chevy Duramax w/ Allison Transmission (5.4L V-8 & Smaller) <i>[3/4-16 Thread]</i>
941842	# 90		F	
941960	# 91		M	Ford F-250 & F-350 (Powerstroke & Gasoline w/ Torqueshift Transmission) <i>[3/4-18 Thread]</i>
941961	# 92		F	
941080	# 93		M	Ford Focus / Mercury Mystique <i>[5/8-18 Thread]</i>
941081	# 94		F	
941899	5/8" Adapter		M	Chevy Duramax w/ Allison Transmission (6.0L V-8 & Larger) [Adapter mates with Hose #51]
941900	# 149		F	
940388	# 124		M	Dodge 3500 Cummins Turbo <i>[3/4-18 Thread]</i>
940389	# 142		F	
940328	1/2" Adapter		M	Ford F-250, 350, 450 & Excursion [Adapter + Hose #66] Dodge Truck V6 & V8, Jeep Grand Cherokee
941809	# 59		F	
941910	3/8" Adapter		M	Ford F-150, Explorer, Edge; Cadillac STS (2006 & 2007) (Release with Ford Style Quick Disconnect Tool for 2007) [Adapter mates with Hose #66]
941805	# 55		F	
942169	1/2" Adapter		M	GM 3/4 & 1 Ton w/ Allison Transmission (2002 & Newer) Dodge 2500 [Adapter mates with Hose #66]
941809	# 59		F	