

### SETUP



Connect red and black battery cables to vehicle's battery.



Fill the DEF8000 with new DEF using the cap port on the back of the machine. The tank is capable of holding 30 gallons of new DEF.

### OPERATION



Move switch on the front panel of the machine in the "FILL" position. The pump will begin to run in bypass when the switch is actuated.



Using the nozzle, fill the vehicle's DEF reservoir with new DEF fluid. The nozzle has a built in vacuum shut off feature that will shut off the flow of DEF when the vehicle's reservoir is full.



When DEF fill is complete, place the nozzle back into the water bath on the side of the machine to ensure proper function of the vacuum shutoff.



Return switch on the front panel of the machine to the "OFF" position.



Disconnect red and black battery cables from the vehicle's battery.



The water bath can be easily drained and refilled using the ball valve at the bottom of the tube. Simply fill the tube with water and open the ball valve to drain it and periodically change the water in the bath.